

# TITEBIKE™ .com

## Yamaha YZF 2006-2008 R6 Frame Sliders

### INSTALLATION INSTRUCTIONS

#### Right side installation:

1. Remove the stock motor mount bolt, set aside as it is no longer needed
2. Take the 90mm bolt and the longest aluminum insert and slide them both into the *shorter* of the two plastic sliders.
3. Put a drop of blue medium strength lock tight on the bolt threads and install the slider assembly into the now vacant motor mount location.
4. Tighten to factory recommended torque spec.



#### Left side installation:

1. Carefully remove the mid fairing from the left side of the motorcycle
2. Remove the stock motor mount bolt, save it as it will be re-used
3. Bolt the aluminum offset plate to the motor mount location using the 60mm bolt provided, blue lock tight and tighten to factory torque spec. The threaded holes in the offset plate should be facing toward the radiator.
4. Now take the motor mount bolt you set aside, and last aluminum insert and slide them thru the plastic slider and mount to the offset plate and torque to 28.ft lbs. The threaded hole that is closest to the frame will fit the 2008 r6.



The purchaser releases seller, from all liabilities pertaining to the installation and use of all parts purchased. It is recommended that the purchaser use a qualified technician to install any parts. Purchaser recognizes that any modification of a vehicle may increase the risk of injury or accident, and will hold harmless all parties involved in this purchase.

[WWW.TITEBIKE.COM](http://WWW.TITEBIKE.COM)  
11757 W. KEN CARYL AVE.  
#F-129  
LITTLETON, CO 80127  
SERVICE@TITEBIKE.COM  
(720) 891-4907